



1. Slide C-Mount camera tube out (don't loosen clamping screw)
2. Remove blue dust cap
3. Attach to camera
4. Plug camera into output tube and rotate until square, lock off using clamping screw
5. Repeat for other port(s)

Note: If focus cannot be achieved, repeat steps 3-5 without the calibration ring and move in Z until focussed